Autonics

THUMBWHEEL SWITCH SETTING TYPE TEMPERATURE CONTROLLER

T3/T4 SERIES



Thank you for choosing our Autonics product.

Please read the following safety considerations before use

■ Safety Considerations

se observe all safety considerations for safe and proper product operation to avoid hazards.

⚠Caution Failure to follow these instructions may result in personal injury or product damage.

he symbols used on the product and instruction manual represent the following ▲ symbol represents caution due to special circumstances in which hazards

⚠ Warning


- I. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment e/disaster prevention devices, etc.)
- Failure to follow this instruction may result in personal injury, fire, or economic loss. 2. The unit must be installed on a device panel before use
- Failure to follow this instruction may result in electric shock 3. Do not connect, repair, or inspect the unit while connected to a power source
- Failure to follow this instruction may result in electric shock
- ${\bf 4.} \ {\bf Check \ the \ terminal \ numbers \ before \ connecting \ the \ power \ source.}$
- Failure to follow this instruction may result in fire
- Do not disassemble or modify the unit. Please contact us if necessary.
 Failure to follow this instruction may result in electric shock or fire.

▲ Caution

- I. Do not use the unit outdoors.
 Failure to follow this instruction may result in shortening the life cycle of the unit, or electric shock. Use the unit indoors only. Do not use the unit outdoors, where it may be affected out
- external environmental factors.

 2. When connecting the power input and relay output cables, use AWG20 (0.05mm²) cables and make sure to tighten the terminal screw bolt above 0.74N·m to 0.90N·m. Failure to follow this instruction may result in fire due to contact failure.

 3. For crimp terminal, select the following shaped M3.5 terminals.



- 4. Use the unit within the rated specifications.
 Failure to follow this instruction may result in shortening the life cycle of the unit, or fire.
- 5. Do not use loads beyond the rated switching capacity of the relay contact.

 Failure to follow this instruction may result in insulation failure, contact melt, contact failure,
- 6. Do not use water or oil-based detergent when cleaning the unit. Use dry cloth to clean 6. Do not use water or oil-based detergent when statement the unit.
 Failure to follow this instruction may result in electric shock or fire.

 7. Do not use the unit where flammable or explosive gas, humidity, direct sunlight, radiant heat, vibration, or impact may be present.
 Failure to follow this instruction may result in fire or explosion.


 8. Keep dust and wire residue from flowing into the unit.
 Failure to follow this instruction may result in fire or product damage.


 9. Check the polarity of the measurement input contact before wiring the temperature sensor.


sensor.

Failure to follow this instruction may result in temperature measurement error.

Ordering Information







1. Present temperature (PV) display

It turns ON when control output is ON.

XIn case of the T3S, the upper DOT of last digit flashes.



alarm output is ON (only for alarm output model) In case of the sub output model (T3HS), the sub (SUB) indicator turns ON when sub output is ON.

4. Set value (SV) thumbwheel switch

Switch for setting temperature.
(-) button: Decreases number, (+) button: Increases number

(-) button: Decreases number (+) button: increases number If the setting is out of the temperature range of temperature sensor, the present temperature (PV) display part flashes 5_{ωEr} and the present value in turn.

**The models which temperature range is 0 (-99.9 to 199.9°C, -99 to 199°C) of temperature sensor DPt100Ω are only set 1↔0↔ (-).

**The dual setting output model (T4LP) has two thumbwheel switches.

LO SET (low set output): heating control, HI SET (high set output): cooling control

5. Hysteresis/Proportional width volume switch (except T3S)

ON/OFF control: Setting for hysteresis. [Setting range] F.S. 0.2 to 3% (For T3S, F.S. 0.5% fixed)

Proportional control: Setting for proportional widt [Setting range] F.S. 1 to 10% (For T3S, F.S. 3% fixed) Proportional cycle: 20 sec. fixed

6. Alarm output value volume switch

It sets alarm output value. (only for alarm output model) [Setting range] F.S. 0 to 10%

7. RESET volume switch

In case of proportional control, it sets offset. [Setting range] F.S. -3 to 3%

the set sub-output temperature (SV). [Setting range] 0 to 50°C

8. Temperature setting of sub output volume switch (only for T3HS) It sets temperature of the sub output. This output operates as deviation low-limit alarm based on

X1: Socket (PG-08, PS-08(N)) is sold separately ※2: Output by Series T3S T3H T3HA T3HS T4M T4MA T4L T4LA T4LP

※ 3	: Input ty	pe and temperat								
Input type			Series Model	T3S	ТЗН	ТЗНА	T3HS	T4M T4MA	T4L T4LA	T4LP
T C	K (CA)	0 to 400°C	4	•	•	•	•	•	•	•
		0 to 800°C	8	•	•	•	-	•	•	•
		0 to 999°C	A	-	•	•	-	-	-	-
		0 to 1200°C	С	-	-	Ī-	-	•	•	•
	J (IC)	0 to 200°C	2	•	-	Ī-	-	-	-	-
		0 to 400°C	4	•	•	•	•	•	•	•
		0 to 800°F	8	-	•	Ī-	-	-	-	-
	R (PR)	600 to 1600°C	F	-	-	-	-	•	•	•
R T D	DPt 100Ω	-99.9 to 199.9°C	0	-	-	-	-	•	•	-
		-99 to 199°C	0	-	•	•	-	-	-	-
		0 to 99.9°C	1	•	•	-	-	-	-	-
		0 to 200.0°C	2	-	-	-	-	-	-	•
		0 to 200°C	2	•	-	T-	-	-	-	-
		0 to 400°C	4	•	•	•	•	•	•	•

input value is higher than the

temperature range of the senso

emperature range of the senso

X1: T4LP (Dual setting output) is the single output


X2: When 5 LEr and o PEn/HI

in turn and all output turns OFF.

ature range of the sen

Flashes when the measured input value is lower than the

Flashes with the present value




When the measured

The set value should be

within the temperature range of the sensor.

HH/LLLL occur at the same time, 5 LEr and oPEn/HHHH/LLLL flash

Panel cut-out



Caution During Use

1. Please use separated line from high voltage line or power line in order to avoid inductive noise.
2. Please install power switch or circuit-breaker in order to cut power supply off.
3. The switch or circuit-breaker should be installed near by users.
4. This unit is designed for temperature controlling only. Do not apply this unit as a voltage meter.

must be used with the same thickness as the line. It might cause temperature difference if the

resistance of line is different. 6. In case of making power line and input signal line close, line filter for noise protection should be

6. In case of making power line and input signal line close, line filter for noise protection should be installed at power line and input signal line should be shielded.

7. Keep away from the high frequency instruments. (high frequency welding machine & sewing machine, big capacitive SCR controller.

8. This unit may be used in the following environments.

(a) Altitude up to 2,000m.

(b) Pollution degree 2.

(c) Installation category II.

(c) Wealtine to follow these instructions may result in product damage.

■ Major Products

_{∏} =

T3S T3H T4M

T 1 2

 Min. 65
 Min. 65
 45 °a
 45 °a
 45 °a

 Min. 65
 Min. 115
 45 °a
 92 °a
 92 °a

 Min. 90
 Min. 90
 68 °a
 68 °a
 68 °a

 Min. 115
 Min. 115
 92 °a
 92 °a
 92 °a

Area sensors roximity sensors Panel meters

OVERSEAS SALES: #402-404, Bucheon Techno Park, 655, Pyeongcheon-ro, Wonmi-gu, Bucheon, Gyeonggi-do, Korea TEL: 82-32-610-2730 / FAX: 82-32-329-0728

■ HEADQUARTERS:

Graphic/Logic panels
Field network devices
Laser marking system (Fiber, CO₂, Nd:YAG)
Laser welding/cutting system

EP-KE-03-0390A

Autonics Corporation

Trusted Partner In Industrial Aut